
Tonometer needs to be vertical to the lid

- the sound will stop when you hold diaton vertically.



Gently, lower the tonometer down (do not press on the eyeball), until short beeping. Then tilt the Tonometer back to get the floater inside. Do not release or change position of the eyelid.



STEP 7

Take the 2-nd measurement on the same place the way it was done during the 1st measurement, then the 3-rd measurement, after long beep press the Operation button.





During the series of measurements the serial number of the measurement appears on the display. (-1, -2, -3,...)







Phone: +7 4912 298 520 E-mail: diaton@grpz.ru

www.diaton-tonometer.com





Measuring of Intraocular Pressure Through the Eyelid

QUICK START GUIDE

Helpful Tips and Pointers




Incorrect tonometer use will provide poor results!

STEP 1

Patient's head must be in a horizontal position.

Patient's thumb can be used as a pointer and the glance should be fixed at a 45 degree angle.



STEP 2

Take the tonometer correctly and switch it on.



Fix the floater in start position.

STEP 3



Pull on the lid with your index finger to make sure the edge of the lid coincides with the limbus (about 1 mm above the cornea). Maintain this eyelid position during the measurement.





The tip of the tonometer must be placed over the tarsus (right behind eyelashes). Rest the edge of your palm on the patient's forehead for support and stability.

STEP 5

